



STR40/45

Note!

This is an indicative recommended spare parts list based on a standard, basic STR40/45 spreader. Order shall not be placed based on the specific article numbers included before verifying the configuration of your specific spreader configuration and serial number.

Please contact parts@bromma.com for a complete list, specific for your spreader and to receive a quotation based on the specific list. Please include your spreader serial number for such requests.

Article Number	Description	Quantity/Spreader
TELESCOPIC BEAM UNIT		
1701427	Twistlock pin kit	2
43653	Twistlock arm (type 1)	1
57059	Twistlock arm (type 2)	1
41683	Spherical washer	2
1000987	Blockading pin kit	1
MAIN FRAME		
38053	Glide plate assembly	4
38073	Chain assembly	1
49854	Landing buffer soft assembly	4
46753	Mounting details powerpack	2
400244	End stop assembly	2
TWIN UNIT		
23528	Twinlift cyliner	1
49841	Shaft twin	1

Article Number	Description	Quantity/Spreader
TWIN UNIT		
49842	Bushing twin	1
1003745	Blockading piece	1
HYDRAULIC SYSTEM		
73096	Direction valve	1
74147	Hydraulic cylinder twistlock	1
74146	Seal kit twistlock cylinder	2
70422	Solenoid DG4V-3	1
700673	Filter element HYDAC 0160 10MY	1
700674	Filter element 8ZZ10	1
78960	Airbreather	1
45965	Plug VSTIR 1/2" complete	1
ELECTRICAL		
79292	Cable connector 1,5 M	1
70395	Cable connector 5 M	1
78986	Auxiliary contactor	2
1702972	Proximity switch	2

